

# Waters & Farr Technical Guide

## Field Hydrostatic Pressure Testing Of Polyethylene Pressure Pipelines

Field testing is performed on fully assembled pipelines for the purpose of determining pipeline acceptability. Following visual acceptance of joints and pipeline components, pressure pipelines in their entirety or in sections are subjected to hydrostatic pressure testing revealing the occurrence of joining/installation faults and confirming the structural integrity and fitness of the pipeline for its intended application. Destructive testing of randomly/regularly cut fusion joints may predate the field pressure testing.


Polyethylene pressure pipeline field testing procedures outlined below are based on recommendations of AS/NZS 2566.2:2002 and AS/NZS 2033:2024, and include:

- Constant pressure test (water loss method).
- Pressure rebound method.
- Visual pressure test (AS/NZS 2033:2024).
- Pressure decay method (AS/NZS 2566.2:2002).

**A hydrostatic test pressure of 1.25 times the maximum working pressure shall be applied to the pipeline section under test. The test pressure at any point shall be not less than the design pressure and not more than 1.25 times the rated pressure of the lowest rated pipeline component. At least two calibrated test gauges must be used to ensure this requirement.**

Refer to AS/NZS 2033:2024 for the testing of pipelines where there is significant elevation difference along the pipe system, or when temperature of pipe walls or of water inside the pipes under testing exceeds 25°C.

Typical field pressure test equipment layout is shown below (source - AS/NZS 2566.2:2002, Figure M2).



**Pre-test procedures include the following:**

- All required temporary and permanent thrust blocks shall be in place and all concrete adequately cured.
- Temporary or permanent test section blanking arrangements (like blank flanges or caps, closed valves) shall be of adequate loading capacity and shall be strutted or anchored for the whole duration of the test unless they are already fully restrained or are end load resistant.
- Where practicable, all bolted joints shall be left exposed to allow for re-tensioning, and other joints shall be left exposed for visual leak detection.
- The test equipment shall be placed in position and checked for satisfactory operation.
- The pump shall be of adequate size to raise and maintain the test pressure.
- Confirm that power supply to all test equipment will last for the duration of the test.
- Pressure in the pipe system shall be logged at 2 s (unless otherwise specified by the relevant authority) intervals throughout the test period, including pipe system filling.
- Arrangements shall be made for the disposal of water flushed or drained from the pipe system, especially if the water has been chlorinated for disinfection of the line.
- The pipeline pressurizing time shall not exceed 45 minutes (usually is planned to be 15 minutes). The pressurizing time affects the duration of the test.
- The pipeline (test section) shall be filled with water from the lowest point ensuring air is vented at the high point valves. The recommended rate of filling based on flow velocity of 0.05 m/s is calculated from the following equation:

$$Q_f \leq 12.5\pi D^2,$$

where  $Q_f$  – filling rate, in l/s,  
 $D$  – pipe internal diameter, in m.

A firm foam swab may be used ahead of the fill water to assist air removal especially where the pipeline undulates. The swab is extracted at a high point wash-out.

- The test section shall be left to stabilize overnight, if possible, or for a minimum period of 3 h, to allow the temperature to stabilize and dissolved air to exit the system.

All necessary safety precautions must be observed including installation of safety barriers where required. Pressure acceptance testing of PE pipe systems shall only be carried out under the direct supervision of a competent person.

**Constant pressure test**

Constant pressure test (water loss method) is regarded as independent of soil support and is sometimes referred to as a reference test.

The procedure of the constant pressure test is initiated as follows:

- Purge the air from pipeline.
- Apply the specified system test pressure (STP) to the test section. Shut off main and allow pressure to settle for 12 h (pressure will drop significantly).
- As possible, inspect for leaks during this period. Where the pressure drops to less than or equal to 70% of the STP after the pre-load time, a leak is probable.
- If a leak is detected, repair and re-start the test at pre-load phase after at least 24 h to allow pipe to relax.
- Calculate the maximum allowance for make-up water:

$$V_{allow} \leq 0.14LDH,$$

where  $V_{allow}$  – Maximum litres of make-up water allowed in 1 hour,  
 $L$  – length of the test section, in km,  
 $D$  – nominal internal diameter of the test length, in m,  
 $H$  – average test head over length of the test section, in m head (taking into account elevation, if applicable).

- Using water of the same temperature as that in the pipeline ( $\pm 3^\circ\text{C}$ ) restore to STP every hour for 5 h measuring and recording the required volume of water. Restore pressure to STP  $\pm 1$  kPa at the end of each hour, within  $\pm 1$  minute.

- Measure and record water volume ( $V_1$ , in l) required to restore pressure to STP at the end of hour 3 from start.
- Measure and record water volume ( $V_2$ , in l) required to restore pressure to STP at the end of hour 5 from start.
- Water volume added shall be to the nearest 0.01 l for short test sections.
- Calculate:  $0.55 V_1 + V_{allow}$
- **The test section shall be acceptable** if:  $V_2 \leq 0.55 V_1 + V_{allow}$ .  
**The test section shall not be acceptable** if the above criterion is not satisfied.  
**The test section shall not be acceptable** also if there is a failure of any pipe component or visible leakage.

**After testing, pipelines shall be depressurised slowly.** All air venting facilities shall be open when emptying pipelines. The test water shall be drained to an approved waterway and all connection points shall be reinstated. The faults shall be detected and corrected, and the pipeline retested.

### Pressure rebound method

Pressure rebound method is a quicker way to confirm absence of leaks and is also regarded as independent of soil support. It is applicable for PE pressure pipelines up to and including DN 315.

This test relies on the pressure vs time response of a pipe that has not been stressed by internal pressure  $> 0.5 \times PN$  within the last 2 h. If the pipe system under test has been subjected to pressure  $> 0.5 \times$  pipe PN, the pressure shall be reduced to  $< 0.5 \times$  pipe PN for 2 h before commencing the test.

The test procedure includes three phases.

#### **Preliminary phase**

- Depressurized pipeline (pressure is just above atmospheric at the highest point of the test section) is allowed to relax for 2 h (no air shall enter the system).
- Pressurize the test section smoothly to the specified test pressure (**STP**) in less than 10 min. Hold the pressure at STP for 30 min., pumping as needed (do not exceed STP). Inspect for leaks during this period.
- Shut off pressure, allow pressure to decay for 60 min.
- Measure the pressure remaining for 60 min. ( $P_{60}$ ).
- If  $P_{60} \leq 70\%$  of STP, the test has failed. Following rectification of the cause, the above steps shall be repeated. If  $P_{60} > 70\%$  of STP, proceed to the second phase.

#### **Air volume assessment**

- Quickly (<5 min.) reduce pressure by  $\Delta P$  (10%-15% of STP) – measure accurately.
- Accurately measure water volume bled out ( $\Delta V$ ).
- Calculate  $\Delta V_{max\ allowable}$  as follows:

$$\Delta V_{max\ allowable} = 1.2 \times V \times \Delta P \times \left( \frac{1}{E_W} + \frac{D}{eE_R} \right)$$

- where
- 1.2 – air allowance,
  - $V$  – pipe volume, in l,
  - $\Delta P$  – measured pressure drop, in kPa,
  - $D$  – pipe internal diameter, in m,
  - $e$  – pipe wall thickness, in m,
  - $E_R$  – pipe material modulus, in kPa (see table below; source - AS/NZS 2566.2:2002, Table M1, assuming MDPE for PE80 and HDPE for PE100),
  - $E_W$  – bulk modulus of water, in kPa (see table below; source - AS/NZS 2566.2:2002, Table M2).


Pipe material modulus $E_p$ for PE 80B and PE 100							Bulk modulus $E_w$ - water	
Temp., °C	PE 80B – $E$ Modulus (kPa $\times 10^3$ )			PE 100 – $E$ Modulus (kPa $\times 10^3$ )			Temp., °C	Bulk Modulus (kPa $\times 10^3$ )
	1 h	2 h	3 h	1 h	2 h	3 h		
5	740	700	680	990	930	900	5	2080
10	670	630	610	900	850	820	10	2110
15	600	570	550	820	780	750	15	2140
20	550	520	510	750	710	680	20	2170
25	510	490	470	690	650	630	25	2210
30	470	450	430	640	610	600	30	2230

- If  $\Delta V > \Delta V_{max\ allowable}$ , there is too much air in the line. Stop the test, vent air from the line, re-start the preliminary phase after at least 2 h of relaxation. If  $\Delta V < \Delta V_{max\ allowable}$ , proceed to the main phase.

**Main test phase**

- Observe and record the pressure rise for 30 min.
- **The test section shall be acceptable** if the pressure do not drop below the rebound peak within 20 min from the pressure drop.
- If in doubt, increase the monitoring period to 90 min. **The test section shall be acceptable** if the pressure drop from the rebound peak does not exceed 20 kPa over the 90 min period.
- **The test section shall not be acceptable** if the pressure drops by more than 20 kPa during the 90 min period.
- **The test section shall not be acceptable** also if there is a failure of any pipe component or visible leakage.

Typical successful extended period rebound test for a PE pipeline is shown below (source - AS/NZS 2566.2:2002, Figure M5).



After testing, pipelines shall be depressurised slowly. All air venting facilities shall be open when emptying pipelines. The test water shall be drained to an approved waterway and all connection points shall be reinstated.

The faults shall be detected and corrected, and the whole test shall be repeated.

**Visual test** is typically used for small diameter pipe systems, for non-critical applications, for short (up to 50 m) pipe sections, or where the joints are accessible for inspection.


**Test method**

- Fir a logging pressure gauge to record test pressure during the test.
- Fill the pipe with water and raise the pressure to STP while bleeding trapped air from the system.
- Keep the system under pressure (pumping if necessary) for at least 10 min.
- **The test section shall be acceptable** if there is no failure of any pipe system component, no visible leakage at any joint or fitting, and the pressure did not drop for more than 20 kPa within 10 min.

Where a leak is detected, it shall be repaired, and the pipeline shall be re-tested.

**Pressure decay test**

Due to creep response and stress relaxation of the material, the test pressure applied to a leak-free polyethylene pipeline will decay in a non-linear manner as shown on figure to the right (source - AS/NZS 2566.2:2002, Figure 6.1). When expressed in logarithmical



coordinates, the result is expected to be a straight line (like line A-B). A change to a steeper slope (line A-C) indicates leakage in the system; initial flatter slope (line A-D) indicates air entrapment at the start of the test.

The procedure of the pressure decay test is initiated as follows:

- Apply the specified test pressure (STP) by pumping water continuously at a constant rate and isolate the high point air release valves and the pump feed valve by closing them.
- Monitor and record the pressure rise and the time taken (loading time  $t_l$ ) to reach the test pressure.

Apply the three-point analysis test procedure as follows:

- At the moment of valve closure, time  $t = 0$ .
- Take the first reading of pressure  $P_1$  at  $t_1$ , where  $t_1 = 0 + t_l$  (see the diagram on the next page; source - AS/NZS 2566.2:2002, Figure M4).
- Take a second reading of pressure  $P_2$  at a  $t_2$  (approximately  $7 \times t_l$ ).
- Take a third reading of pressure  $P_3$  at a  $t_3$  (not less than  $15 \times t_l$ ).
- To allow for the creep behaviour of PE pipeline whilst being pressurised, calculate the corrected values of  $t_1$ ,  $t_2$  and  $t_3$  as follows:

$$t_{1c} = t_1 + 0.4 \times t_l$$

$$t_{2c} = t_2 + 0.4 \times t_l$$

$$t_{3c} = t_3 + 0.4 \times t_l$$

- Calculate the slope of the pressure decay curve between  $t_1$  at a  $t_2$  (slope  $n_1$ ) using:

$$n_1 = (\log P_1 - \log P_2) / (\log t_{2c} - \log t_{1c})$$

and between  $t_2$  at a  $t_3$  (slope  $n_2$ ) using:

$$n_2 = (\log P_2 - \log P_3) / (\log t_{3c} - \log t_{2c})$$

- **The test section shall be acceptable** (no leakage) if  $n_1$  and a  $n_2$  lie within the range 0.04 to 0.1, as follows:
  - ◆ 0.08 – 0.10 for unsupported pipes (e.g., slip lined or no backfill).
  - ◆ 0.05 – 0.08 for pipes in intermediate ground conditions.
  - ◆ 0.04 – 0.05 for pipes in compacted backfill.


Note, that some environmental factors leading to significant change of pipeline temperature during the procedure may contribute to small deviations from the above range.

The test section is also acceptable if the plotted line is not straight, but is within the above range for the second slope (the first slope was shallow – initial entrapment of a small amount of air; the first slope was slightly steeper – possibly due to a small steep drop of pressure prior to  $t_1$ ) or, being within the above range for the first slope, becomes shallow for the second slope (possibly due to pipe reaching an obstruction for expansion).

The test section shall not be acceptable when the plotted line is not within the above range for both slopes or is steeper for the second slope. The following interpretations may provide guidance:

- ♦  $n < 0.04$ : there is probably air in the system.
- ♦  $n > 0.10$ : the system is probably leaking.
- ♦  $n \gg 0.15$ : there is almost certainly a leak.

The test section shall not be acceptable if there is a failure of any pipe component or visible leakage.



Problems with pipelines may be predicted earlier by comparing the actual pressure with the predicted pressure, which is calculated using the following equation:

$$P = P_L (2.5(t/t_L) + 1)^{-n},$$

- where  $P$  – predicted pressure at time  $t$ ,  
 $P_L$  – test pressure at start of test,  
 $t_L$  – loading time,  
 $n$  – slope of the pressure decay curve (may be taken as 0.10 for pipes without constraint, or as 0.05 for pipes with compacted backfill).

After testing, pipelines shall be depressurised slowly. All air venting facilities shall be open when emptying pipelines. The test water shall be drained to an approved waterway and all connection points shall be reinstated.

The faults shall be detected and corrected, and the pipeline retested.

The minimum time between repeat tests shall be at least 5 times the total test time.

Test reports usually include full details of the pipeline tested, test method, test station location, dated test data and results, water and ambient temperatures, details of faults, dated retest data and results.

For more detailed description of procedures for field testing of PE pipelines refer to AS/NZS 2033 and AS/NZS 2566.2 as reference documents.